FOR ORD 10.09 (2020R3) NCDOT Connect WorkSpace Update Version 7.2.9


 For everyone's awareness, there is an updated NCDOT Connect WorkSpace, Version 7.2.9, that is available for download and further testing during our ORD Implementation Initiative Pilot Project Phase.

Upgrades and fixes include:


1) **Target CCE** - All targeted Construction Class Elements (CCE) placed by the users will have a weight of 10 and higher priority for legibility over CCEs automatically drawn by the templates (weight = 0).

2) AASHTO_2018_English-NCDOT.xml


- a. Customized Speed Tables for even increment Runoff and Runout distances foe 15 thru 80 MPH design speeds.
- b. Speed Tables expanded from 2-lane rotated to 5 -lane rotated.



3) **NCDOT_Superelevation_Even_Increments.xlsx** – Verify superelevation even incremental transitions.



4) Drawing Seeds – Disassociated WorkSets from all NCDOT Drawing Seeds.




- 5) **R-2635C (Training).cfg** Reconfigured Training Workset to work with various template libraries (ITL) for training modules:
 - a. Module 5 Initial Corridor Modeling

- b. Module 8 Intermediate Corridor Modeling
- c. Module 9 Detailed Modeling
- d. Module 9.1 Intersection Design

Below are the general steps to update the current NCDOT Connect Workspace to the most recent Version for continued testing and use.

- **Note 1:** The process noted below is a temporary way in the short term for setting up and testing the current version of the NCDOT Connect WorkSpace.
- Note 2: If you want to verify the version of the ZIP file of the NCDOT Connect WorkSpace before
 downloading it under its "Title" properties once you have right clicked on the link to check the
 properties (see screenshot below)



- Perform the NCDOT CONNECT WorkSpace update in the following sequence.
 - 1. Delete the entire "C:\MICROSTATION CONNECT WORKSPACE" folder.
 - 2. Delete the old desktop icons.
 - 3. Download the "MICROSTATION_CONNECT_WORKSPACE-Beta.zip" (see the link below)
 - https://connect.ncdot.gov/projects/Roadway/Training/MICROSTATION CONNECT WORKSPACE-Beta.zip
 - 4. Unzip (EXTRACT ALL) "MICROSTATION_CONNECT_WORKSPACE-Beta.zip" to the root C:\
 - 5. Copy the new desktop icons from the following WorkSpace folder:

- a. C:\MICROSTATION_CONNECT_WORKSPACE\Configuration\WorkSpaces\DOT-US North Carolina\Desk
- b. At a minimum, the following 3 icons should be copied to the desktop:
 - i. The NCDOT_WorkSets.inp (required)
 - ii. NCDOT ALL (Loads all Unit's Resources)
 - iii. Any Unit Specific Desktop Icon